

vtech[®]

User's Manual

Lil' Cogsley™



2013 VTech®
Printed in China
91-001659-005 (US/CA)

Dear Parent,

At **VTech**[®], we know how important the first day of school is for your child. To help prepare preschoolers for this important event, **VTech**[®] has developed the **Preschool Learning**[™] series of interactive toys.

Preschool Learning[™] features fun characters and inviting school themes that use technology to capture a child's attention and teach important preschool skills like spelling, counting and the alphabet. These vital skills are taught in a way that's both fun and highly engaging to maintain a child's interest. Children will also be introduced to fun school subjects such as art class, music class and even recess! With **Preschool Learning**[™], learning is fun from day one!

At **VTech**[®], we know that a child has the ability to do great things. That's why all of our electronic learning products are uniquely designed to develop a child's mind and allow them to learn to the best of their ability. We thank you for trusting **VTech**[®] with the important job of helping your child learn and grow!

Sincerely,


Your friends at **VTech**[®]

To learn more about **Preschool Learning**[™] series and other **VTech**[®] toys, visit www.vtechkids.com

INTRODUCTION

Thank you for purchasing **Lil' Cogsley™** from **VTech®**.

Lil' Cogsley™ is a funny, friendly robot pal who loves to talk, teach, play and dance. He has five different modes of play that introduce letters, letter sounds, vocabulary words, telling time, creativity, music and more. There's always something fun to do when **Lil' Cogsley™** is around.



INCLUDED IN THIS PACKAGE

- One VTech® Lil' Cogsley™
- One user's manual


WARNING: All packing materials, such as tape, plastic sheets, packaging locks and tags are not part of this toy, and should be discarded for your child's safety.

ATTENTION: Pour la sécurité de votre enfant, débarrassez-vous de tous les produits d'emballage tels que rubans adhésifs, feuilles de plastique, attaches et étiquettes. Ils ne font pas partie du jouet.

Note: Please keep this user's manual as it contains important information

DEMO STRIP REMOVAL: When the product is taken out of the packaging, please remove the demo strip from the unit to activate normal play mode.

Unlock the packaging locks:




- ① Rotate the packaging locks 90 degrees counter-clockwise.
- ② Pull out the packaging locks.

GETTING STARTED

BATTERY INSTALLATION

1. Make sure the unit is OFF.

2. Locate the battery cover at the back of the unit.
3. Use screwdriver to open the battery cover.
4. Install 2 new “AA” Size (AM-3/LR6) batteries following the diagram inside the battery box. (The use of new alkaline batteries is recommended for maximum performance.)
5. Replace the battery cover.



Important Note: After changing batteries, the clock will be reset. Please adjust the display time within Settings.

BATTERY NOTICE

- Use new alkaline batteries for maximum performance.
- Use only batteries of the same or equivalent type as recommended.
- Do not mix different types of batteries: alkaline, standard (carbonzinc) or rechargeable (Ni-Cd, Ni-MH), or new and used batteries.
- Do not use damaged batteries.
- Insert batteries with the correct polarity.
- Do not short-circuit the battery terminals.
- Remove exhausted batteries from the toy.
- Remove batteries during long periods of non-use.
- Do not dispose of batteries in fire.
- Do not charge non-rechargeable batteries.
- Remove rechargeable batteries from the toy before charging (if removable).
- Rechargeable batteries are only to be charged under adult supervision.

PRODUCT FEATURES

1. GAME BUTTON

Press the **GAME BUTTON** to switch from Clock mode to Game mode and then select a game.



2. CLOCK BUTTON

Press the **CLOCK BUTTON** to switch from Game mode to Clock mode.



3. OK BUTTON

Press the **OK BUTTON** to confirm your choice.



4. TUMMY DIAL

Turn the **TUMMY DIAL** to scroll through the menu or make a selection in a game. Spin it quickly to see some surprise reactions from **Lil' Cogsley™**.



5. MOVING HEAD AND ARMS

Lil' Cogsley™ will shake his head and arms while playing. Please avoid holding his head or arms while he shakes.

6. ALARM CLOCK

Set the alarm clock within Settings. When the alarm sounds, press any button to turn it off.

7. AUTOMATIC SWITCH TO CLOCK MODE

To preserve battery life, the unit will automatically switch to clock mode after several minutes without input.

ACTIVITIES:

1. Letter Learning

Lil' Cogsley™ is going to teach you letters and phonics! Turn the **TUMMY DIAL** to choose a letter and press the **OK BUTTON** to confirm.

2. What's That?

Lil' Cogsley™ is trying to learn some earth objects, but the smoke from his spaceship is blocking his view. Help him to clear the smoke by turning the **TUMMY DIAL** so he can see the objects and learn.

3. Spaceship Maker

Lil' Cogsley™ wants to make a brand new spaceship! Turn the **TUMMY DIAL** to find the top and bottom parts for the spaceship. Press the **OK BUTTON** to select each part.

4. Tick Tock

Lil' Cogsley™ has a daily schedule. Turn the **TUMMY DIAL** to choose a time and press the **OK BUTTON** to see what **Lil' Cogsley™** is doing at different times of the day.

5. Robot Rock

Let's dance with **Lil' Cogsley™**! Turn the **TUMMY DIAL** to choose from five fun melodies. When listening to the melody and watching **Lil' Cogsley™**, turn the **TUMMY DIAL** to make funny sounds!

6. Settings

Enter Settings in order to set the clock time and alarm, or adjust the screen contrast and volume. When the alarm has been set, an alarm icon will appear on the screen in Clock mode.

CARE & MAINTENANCE

1. Keep the unit clean by wiping it with a slightly damp cloth.
2. Keep the unit out of direct sunlight and away from any direct heat sources.
3. Remove the batteries when the unit is not in use for an extended period of time.
4. Do not drop the unit on a hard surface and do not expose the unit to excess moisture or water.
5. Do not hold the arms of head of the robot when it is in motion.

TROUBLESHOOTING

If for some reason the program/activity stops working, then please follow these steps:

1. Turn the unit OFF.
2. Interrupt the power supply by removing the batteries.
3. Let the unit stand for a few minutes, then replace the batteries.
4. Turn the unit back ON. The unit should now be ready to play again.
5. If the product still does not work, replace with an entire set of new batteries.

If the problem persists, please call our Consumer Services Department at 1-800-521-2010 in the U.S. or 1-877-352-8697 in Canada, and a service representative will be happy to help you.

IMPORTANT NOTE:

Creating and developing Preschool Learning products is accompanied by a responsibility that we at VTech® take very seriously. We make every effort to ensure the accuracy of the information which forms the value of our products. However, errors sometimes can occur. It is important for you to know that we stand behind our products and encourage you to call our Consumer Services Department at 1-800-521-2010 in the U.S., or 1-877-352-8697 in Canada with any problems and/or suggestions that you might have. A service representative will be happy to help you.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.

- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.